


# Commsplus Self Help

Program system speed dial numbers



## To program speed dial numbers:

Put the handset on hook

Press the following:

**TRANSFER**

200

1234

1

**SPEAKER**

705

**VOLUME +/-** (until correct speed dial no. is displayed)

**RIGHT HAND SOFT BUTTON** (under the display)


**VOLUME +/-** (until correct speed dial no. is displayed)

To program more speed dial numbers repeat above steps

**TRANSFER** (to save and exit)

# Commsplus Self Help

Program system speed dial names



## To program speed dial names:

Put the handset on hook

Press the following:

**TRANSFER**

**200**

**1234**

**1**

**SPEAKER**

**706**

**VOLUME +/-** (until correct speed dial no. is displayed)

**RIGHT HAND SOFT BUTTON** (under the display)

**HOLD** (to delete existing name)

**TYPE THE NAME** (for space use volume +/-)

**RIGHT HAND SOFT BUTTON** (under the display)

**VOLUME +/-** (until correct speed dial no. is displayed)

To program more speed dial numbers repeat above steps

**TRANSFER** (to save and exit)