
Commsplus Ltd.

To program System Speed Dial numbers

WITH THE HANDSET ON HOOK

DIAL (PRESS):

TRANSFER

200

1234

1

SPEAKER

705

VOLUME +/- (until correct speed dial no. is displayed, starts at 500)

RIGHT HAND SOFT KEY (button under display)

HOLD (to delete previous no. if needed)

ENTER THE NUMBER (500: 9-01934882200)

RIGHT HAND SOFT KEY (button under display)

VOLUME +/- (until correct speed dial no. is displayed)

THEN FOLLOW ABOVE STEPS TO PROGRAM MORE SPEED DIALS

TRANSFER TO EXIT

To program System Speed Dial name

WITH THE HANDSET ON HOOK

DIAL (PRESS):

TRANSFER

200

1234

1

SPEAKER

706

VOLUME +/- (until correct speed dial no. is displayed, starts at 500)

RIGHT HAND SOFT KEY (button under display)

HOLD (to delete previous name if needed)

TYPE THE NAME (for C press 2 three times, space use volume +/-)

RIGHT HAND SOFT KEY (button under display)

VOLUME +/- (until correct speed dial no. is displayed)

THEN FOLLOW ABOVE STEPS TO PROGRAM MORE SPEED DIAL NAMES

TRANSFER TO EXIT



T: 01934 882200

F: 01934 882219

www.commsplus.co.uk